

1.

- A. Number of defect classes : 1 class (All defects are classified as defective ;
In MVTec's design, toothbrush's database does not further subdivide defect types).
- B. Types of defect classes : Indicates that the toothbrush is abnormal, such as:
Bristles are skewed 、 Defect or deformation 、 Surface damage, etc.
- C. Number of images used in your dataset :

Split	Class	Number of Images
Training	good	60
Test	good	12
Test	defective	30
Ground truth	defective (mask)	30

- D. Distribution of training and test data :
- ◆ train/good : 60 normal (non-defective) images for training
 - ◆ test/good : 12 normal images for testing
 - ◆ test/defective : 30 defective images for testing
 - ◆ ground_truth/defective : 30 binary mask images that highlight the defect regions.
- E. Image dimensions : All images: 1024×1024 pixels, RGB (3 channels).

2.

Method 1: Partial Fine-Tuning of Pretrained Weights

- Adjustment: : Unfroze some layers of ResNet-18 (e.g., layer4) to allow joint training.
- Result : Test Accuracy: 75.00% ; Helped improve feature extraction but showed instability and signs of overfitting on limited data.
- Pros: Enhanced model flexibility and better adaptation to the dataset.
- Cons: Training and validation accuracy fluctuated significantly.

Method 2: Changing Optimizer to SGD with Momentum

- Adjustment : Replaced the optimizer with SGD and added momentum (0.9).
- Result : Test Accuracy: 50.00% ; Model performance was unstable, and loss values were very high.

- Analysis: SGD can be too sensitive on small datasets, often getting stuck in local minimum.

Method 3 : Enhanced Data Augmentation

- Adjustment: : Applied RandomCrop, RandomHorizontalFlip, ColorJitter, and RandomRotation to the training data.
- Result : Test Accuracy: 62.50% ; Slight improvement in generalization, but not significant.
- Analysis : Data augmentation helped reduce overfitting but alone wasn't enough to achieve high performance.

Method 4: Tuning Learning Rate and Adding Scheduler

- Adjustment : Reduced learning rate from $1e-3$ to $5e-4$; Applied StepLR scheduler to halve the learning rate every 10 epochs.
- Result : Test Accuracy: 87.50% (Best) ; Validation accuracy also reached 87.50%
- Advantages : A smaller learning rate allowed more stable convergence ; The scheduler helped prevent overshooting and refined the learning process.

Best Method : Method 4 (Learning Rate Adjustment and Scheduler)

This method achieved the highest test accuracy of 87.50%, demonstrating that properly tuning the learning rate and using a scheduler significantly improves model stability and generalization. It helped the model converge smoothly and avoid performance drops caused by unstable updates.

3.

(i) A long-tail distribution refers to the phenomenon where a small number of classes (head classes) have many samples, while the majority of classes (tail classes) have very few samples. This imbalance can cause models to be biased towards head classes during training, resulting in poor performance on the underrepresented tail classes.

(ii) They proposed a method called Balanced Group Softmax (BAGS), which divides classes into groups and applies softmax within each group separately. This approach helps balance the classifier training and improves detection performance on long-tail distributions.

To apply this method to the MVTec AD dataset, we could group the 'Good' class separately from the defect classes and apply softmax within each group. This would prevent the model from being overly biased toward the 'Good' class, thereby enhancing its ability to detect defects.

4. Since the training set of the MVTec AD dataset mainly contains 'Good' images and lacks defective samples, it is suitable to adopt unsupervised or self-supervised anomaly detection methods. A common strategy is to train a reconstruction-based model such as an Autoencoder or Variational Autoencoder (VAE) using only normal samples. The model learns to reconstruct normal images, and during testing, defective images yield higher reconstruction errors, which can be used to detect anomalies. Another approach involves using pre-trained feature extractors (e.g., CNNs) and applying distance-based metrics like the Mahalanobis distance to identify abnormal patterns.

5.

(i) To fine-tune an object detection model like YOLO-World, the dataset must include images with bounding box annotations for each defect, along with class labels. For segmentation tasks using models like SAM, pixel-wise annotations are required, where each pixel is labeled as either normal or a specific defect type. These annotations are usually provided in the form of masks.

(ii) These models are well-suited for fine-tuning on our custom dataset because they offer strong feature extraction capabilities and high transferability. YOLO-World can efficiently detect and localize custom defect categories, while SAM excels at precise segmenting regions of interest, which is critical for identifying subtle or irregular defect patterns. Additionally, both are open-source and highly adaptable, making them practical choices for improving anomaly detection accuracy and detail.